



Sidelite & Transom Sizes for In-Swing Doors

1. The drawings in this catalog are not necessarily all scaled the same. Drawings are intended for visual reference only and are not suitable for architectural purposes.
2. Rough Opening Width and Height should typically be 1/2" greater than the Unit/Frame Dimension.
3. Glass Sizes and additional dimensions are available on the Dimensions page at the back of this section.
4. Unit may be mullioned with others to form a combination unit. Rough Opening should be adjusted to account for the additional units. Generally, add the unit dimensions together and add 1/2" for the rough opening.
5. The standard jamb depth is 4-9/16". Jamb Extension may be added to increase the jamb depth to 6-9/16".
6. Unit Sizes have a tolerance of + / - .0625" per frame/unit dimensions

Unit/Frame H.	R.O. Height	Panel Height	13 13/16"	15 13/16"	17 13/16"	Unit/Frame Width
79 1/2"	80"					R.O. Width
82 1/2"	83"					Panel Width
95 1/2"	96"					

Transoms

Unit/Frame H.	25 1/4"	31 1/4"	33 1/4"	37 1/4"	40 1/4"	48 7/8"	60 7/8"	64 7/8"	72 7/8"	Unit/Frame W.
16"	25 3/4"	31 3/4"	33 3/4"	37 3/4"	40 3/4"	49 3/8"	61 3/8"	65 3/8"	73 3/8"	R.O. W.
16 1/2"										