

Casement Shipping Blocks



Sun Casement windows have a Shipping Block installed on the bottom of the operating sash to prevent damage to the sash and operating hardware while the window is being transported. This Shipping Block must be removed during the installation process. Failure to remove the Shipping Block will result in poor performance of the window and possibly the inability to open the sash.

The Shipping Block is pin-nailed to the bottom of the sash. Use a putty knife or other tool to pry the block off of the sash. Be sure the pin nail is removed as well. Failure to remove the pin nail will result in damage to bottom frame member and possibly the inability to open the sash.